

Medium Duty Class 2-6 COMMERCIAL USE ONLY

NTP *ULTRA 2*° MD Truck Protection Plan

Class 2-3 start miles <150,000; contract expires at 300,000 total miles. Class 4-6 start miles <300,000; contract expires at 450,000 total miles. Wrap coverage begins at expiration of prior OEM coverage (by age or mileage).



Included in the **ULTRA 2 Plan**

- No Repair Limits*: Engine, Critical Components, Turbo(s) and Trans & Rear Diff. have no repair cap, including labor.
- Rapid Repair Guarantee Plus®*: If your repair is not completed in a timely manner we'll pay for your truck payment, up to \$1,500.
- Towing Reimbursement*: Three tows during contract term, up to \$350 each

for details

ENGINE, CRITICAL COMPONENTS, TURBO(S) and TRANS & REAR DIFFERENTIAL

TERMS	START MILES	CLASS 2	CLASS 3	START MILES	CLASS 4	CLASS 5	CLASS 6
12 months 60,000 miles	<50K	\$1,579	\$1,629	<100K	\$1,729	\$1,849	\$1,969
	50K < 100K	\$1,679	\$1,739	100K < 200K	\$1,839	\$2,139	\$2,399
	100K-150K	\$1,839	\$1,909	200K-300K	\$2,049	\$2,579	\$2,999
24 months 100,000 miles	<50K	\$2,049	\$2,129	<100K	\$2,269	\$2,569	\$2,759
	50K < 100K	\$2,309	\$2,399	100K < 200K	\$2,549	\$3,029	\$3,459
	100K-150K	\$2,559	\$2,659	200K-300K	\$2,899	\$3,749	\$4,419
36 months 150,000 miles	<50K	\$2,749	\$2,859	<100K	\$3,029	\$3,629	\$3,819
	50K < 100K	\$3,009	\$3,139	100K < 200K	\$3,399	\$4,089	\$4,299
	100K-150K	\$3,259	\$3,399	200K-300K	\$3,649	\$4,809	\$5,249

\$350 deductible per occurrence

Additional Programs and Services

TERMS	AFTERTREATMENT	COMFOR CLASS 2-3	RT PACKAGE [®] CLASS 4-6	RENTAL TRUCK PROGRAM
12 months / 60,000 miles:	+\$1,410	+\$249	+\$449	14 Days:
24 months / 100,000 miles:	+\$2,090	+\$449	+\$649	+\$349
36 months / 150,000 miles:	+\$2,400	+\$649	+\$749	(must match contract term)

Buyer Name _

VIN Number

Date

The above optional items have been offered and fully explained to me prior to my execution of any buyers order. The purchase/non-purchase of any item will not affect my finance rate, credit approval or ability to obtain financing. I/We are choosing to purchase the selected optional service contract above. I/We understand specific details and coverage terms are stated in the respective service contract including all exclusions, limitations and exceptions. The purchase of a service contract is optional. I/We authorize Enterprise to complete my application and registration with NTP.

CUSTOMER **SIGNATURE**

the 30 day/ 3000 mile Enterprise Limited Powertrain Warranty will be the only applicable coverage if no applicable manufacturer warranty coverage remains. The exclusions, limitations and exceptions of the 30 day/3000 mile Enterprise Limited Powertrain Warranty are stated in the disclosure provided at time of sale.

I/We are choosing to decline the optional service contract offers stated above. I/We understand that

CUSTOMER SIGNATURE



Medium Duty Class 2-6

COMMERCIAL USE ONLY

NTP ULTRA 2° MD Truck Protection Plan

OPTIONAL

Model age must be 7 years or newer from current calendar year. Class 2-3 start miles <150.000; contract expires at 300.000 total miles. Class 4-6 start miles <300.000; contract expires at 450.000 total miles. Wrap coverage begins at expiration of prior OEM coverage (by age or mileage).

Aftertreatment (LOL \$8,000)

Back Pressure Control Valve (BPV)

Injection Nozzle

• DEF Heated Lines (3)

• DEF Heating Elements

• DEF Pump and Module

DPF Dosing Module

Exhaust Throttle Valve

Lines; and Inline Air Filter

EGR Actuator

• EGR Cooler(s)

• DFF Tank

DEF Heater Control Relay

· Diesel Exhaust Fluid (DEF) Module with

• DEF Dosing Module - Wiring Harness

• DEF Heating Fittings (3 on Supply Module)

• DEF Solution Level/Temperature Sensor

• Exhaust Gas Recirculation (EGR) Valves

· EGR Connecting Bellows and Clamps

· Exhaust Piping, Clamps, and Gaskets

Hydrocarbon Doser Valve (Voss Valve)

· Selective Catalytic Reduction (SCR) Catalyst

SCR Decomposition Pipe and Pipe Elbows

Hydrocarbon Doser Injector (HC Doser, 7th Injector,

• Hydrocarbon Doser Valve - Air, Fuel, and Coolant

• DEF Heater Coolant Control Valve

• Diesel Oxidation Catalyst (DOC)

• DPF Air. Fuel, and Coolant Lines

. DPF Air, Fuel, Manifold Assembly

Diesel Particulate Filter (DPF)

Aftertreatment Electronic Control Module (ACM)



OPTIONAL

INCLUDED

Covered Components Summary

\$350 deductible per occurrence

CC = Included in Critical Components LOL = Limits of Liability

Coverage Exclusions: Please refer to your vehicle service contract for complete list and details of covered and non-covered items.

Engine (NO LIMITS*)

- · Camshaft and Cam Bearings
- Cam Followers
- Connecting Rods
- . Connecting Rod Bearings
- Connecting Rod Caps and Screws
- Crankshaft
- Cylinder Block Casting
- · Cylinder Head and Head Gasket
- Cylinder Liners
- Cylinder Head Bolts
- Hydraulic Lifters
- Injector Cups
- Intake and Exhaust Valves
- Intake and Exhaust Valve Guides
- · Main Bearings
- . Oil Cooler and Housing
- Oil Pan
- Oil Pump Pick Up Screen and Tube
- Oil Pump Pressure Relief Springs and Valves
- · Pistons, Piston Rings and Piston Oil Cooling Jets
- Pushrods
- Rocker Arms and Rocker Arm Shafts
- Thrust Washers
- . Timing Gears
- Timing Gear Cover and Housing
- Valve Cover
- Valve Retainers and Keepers (Locks)
- Valve Seats and Valve Springs
- Wrist Pins

"Non-oil" related components:

- · Exhaust Manifold
- Flywheel Housing
- Intake Manifold
- Thermostat Housing
- Vibration Dampener

(CC) Engine Fuel Injectors, Water Pump, Fuel Pump & ECM (NO LIMITS*)

- Complete Injector
- Fuel Injector Hard Lines
- Fuel Injection Pump

- Water Pump

- Bearings
- Internal Variable Vane Assembly
- Turbine and Turbine Shaft
- Turbo Actuator

- Bearings
- Blockers
- Bushings
- Control Module
- (TCM)
- Drums Gear Sets
- Thrust Washers • Torque Converter

Power divider

includes:

Bearings

Gears

Shafts

Shift Forks

- Valve Body

Governor

Differential (NO LIMITS*)

- Axle Housing
- · Axle Shafts
- Bearings Bushings
- Carrier Case
- Gear Sets
- · Limited Slip Clutch Pack

- Fuel Pump
- Engine Control Module (ECM)

(CC) Turbo(s) (NO LIMITS*)

Transmission (NO LIMITS*)

- Bands
- Oil Pump
- Shaft(s) · Shift Forks
- Speed Sensor
- Synchronizers

- Sensor, BPV Pressure • Sensor, Delta P (DPF Pressure) Sensor, DOC Inlet Pressure
 - Sensor, DOC (Post) Temperature
 - Sensor, DOC (Pre) Temperature
 - Sensor, DPF Air Supply Pressure
 - Sensor, DPF Back Pressure
 - Sensor, DPF Fuel Pressure
 - Sensor, Lambda (O2 Sensor)
 - Sensor, NOx (2) • Sensor, Pressure After Exhaust Throttle Valve
 - · Sensor, SCR (Post) Temperature · Sensor, SCR (Pre) Temperature
 - Wiring Harness Emission Systems (including overlay)

OPTIONAL

Comfort Package® (LOL \$6,000)

- Alternator
- Charge Air Cooler
- Engine Air Compressor
- Fan Clutch
- Fuel Tanks, Cap. & Valve
- HVAC Air Compressor & Pullev
- HVAC Blower Motor & Resistor
- HVAC Fan Hub
- HVAC Heater Core
- HVAC Temperature Controls. Control Head. & Control Valves
- Radiator & Radiator Cap
- Radio
- · Starter & Starter Solenoid

having their CDL for 2+ years.

Rental Truck Assistance

This program provides reimbursement for a rental truck while your truck is being repaired for a covered claim. We offer a 14-day program and your rental days can be used as needed during your contract term. Rentals must be arranged with an authorized rental truck facility. Maximum reimbursement rates are specified in your contract. Please contact an NTP Co. claims administrator prior to renting for other details. The driver renting the truck is responsible for showing proof of insurance, paying for fuel, mileage charges, and applicable vehicle damage that occurs during the rental period. They may also be asked for a security deposit and proof of

Rapid Repair Guarantee Plus®

This program quarantees that once the claim approval is complete, our National Repair Network will have you on the road within 14 days or we will pay you, or the lienholder, half of your monthly truck payment, up to \$750. If repairs require more than 30 days from the time the claim is approved, we will pay you, or the lienholder, your total monthly truck payment, up to \$1,500.

Progressive Damage, Wearout & Carbon Packing

Please refer to your contract for details on Progressive Damage, Wearout and Carbon Packing coverage.

Underwriting Dealer Requirements Before Sale

Must perform

NTP inspection

requirements and

Co Claims Admin

submit form to NTP

- Perform OEM recommended PM, and install new engine oil and filter.
- · Check and repair/resolve all active and inactive fault codes
- Visually inspect all covered components. Repair/resolve all deficiencies and leaks.
- Perform road test/performance evaluation. Identify and resolve all operating deficiencies for covered components.
- Check engine and aftertreatment performance and repair deficiencies (skips, knocking, exhaust smoke, clogged/dirty filter, etc.).
- · Retain RO's for all repairs.