

90-DAY Powertrain Coverage

Drive with Confidence: Protect Against Unexpected Repairs

BASELINE COVERAGE

> Includes: Engine, Critical Components (turbos, fuel injectors, fuel pump, water pump, ECM and more), Transmission & Rear Differential, and Aftertreatment, or Emissions (Gas engines) and Comfort Package.

BASE COVERAGE LIABILITY (LOL)

Engine	\$10,000
Turbo	\$3,750
Fuel Injectors/Pump, Water Pump, ECM	\$3,125
> Transmission + Rear Differential	\$3,750
Aftertreatment or Emissions	\$3,750
Comfort Package ®	\$3,000
Aggregate Limit	\$15,000/ACV*

TERMS & CONDITIONS

- >
- Class 2-8
 - 90 days/25,000 miles term
 - \$350 deductible
 - Model year <10 years
 - Starting mileage
 - Class 8 <900,000 miles
 - Class 2-7 <175,000 (Gas)
 - Class 2-7 <350,000 (Diesel)

> Protect your equipment from costly repair surprises

Turbos
\$5,000 – \$24,500

Pistons
\$20,000 – \$30,000

Injectors
\$5,000 – \$22,000

Radiator
\$3,000 – \$8,000

Engine
\$11,000 – \$52,000

Transmission
\$6,500 – \$22,000

Fuel Pump
\$5,000 – \$21,000



Engine

INCLUDED

- Camshaft, Cam bearings & Cam followers
- Connecting rods, Connecting rods bearings, Caps and cap screws
- Crankshaft
- Cylinder heads, block casting, head bolts, head gasket & liner
- Exhaust manifold & Flywheel housing
- Hydraulic lifters
- Intake manifold, intake and exhaust valve, valve guides & Injector cups
- Main bearings
- Oil pan, oil cooler and housing
- Oil pump housing, gears, pickup screen, pick up tube, pressure relief springs & pressure relief valves
- Pistons, piston rings & piston oil cooling jets
- Pushrods, rocker arms & shafts
- Thermostat housing
- Thrust washers
- Timing gears, cover and housing
- Valve cover, retainers, seats, springs & keepers (locks)
- Vibration dampener

Engine Fuel Injectors & More (Critical Components)

INCLUDED

- Complete Injector
- Fuel injector pump & hard lines
- Fuel Pump & water pump
- Engine Control Module (ECM)

Turbo (Critical Components)

INCLUDED

- Bearings
- Internal Variable Vane Assembly
- Turbine and Turbine Shaft
- Turbo Actuator

Comfort Package ®

INCLUDED

- Alternator
- Charge Air Cooler
- Engine Air Compressor
- Fan Clutch
- Fuel Tanks, Cal & Valve
- HVAC Air Compressor & Pulley
- HVAC Blower Motor & Resistor
- HVAC Fan Hub
- HVAC Heater Core
- HVAC Temperature Controls, Control Head, & Control Valves
- Radiator & Radiator Cap
- Radio
- Stater & Starter Solenoid

Transmission & Rear Differential

INCLUDED

Transmission:

- Bands
- Bearings
- Blockers
- Bushings
- Control Module (TCM)
- Drums
- Gear Sets
- Governor
- Oil Pump & Shafts
- Shift forks
- Speed Sensor
- Synchronizers
- Thrust Washers
- Torque Converter
- Valve Body

Differential

- Axle Housing
- Axle Shafts
- Bearings
- Bushings
- Carrier Case
- Gear Sets
- Limited Slip Clutch Pack

Power divider includes:

- Bearings
- Gears
- Shafts
- Shift Forks

Emissions Assembly

INCLUDED

- Catalytic Converter
- Evap Canister
- Evap Canister Vent Solenoid
- Exhaust Manifold Gaskets
- Exhaust Pipes (between exhaust manifold & catalyst)
- Fuel Tank Pressure Sensor
- Mass Air Flow Sensor
- Oxygen (O2) Sensors
- Purge Control Valve

Aftertreatment

INCLUDED

- Aftertreatment electronic control module (ACM)
- Back pressure control valve (BPV)
- Diesel exhaust fluid (DEF) module
- DEF injection nozzle, heater control relay, dosing module - wiring harness, heated lines (3), heater coolant control valve, heating elements & fittings (3)
- DEF pump, module & tank
- DEF solution level/temp sensor
- Diesel oxidation catalyst (DOC)
- DOC doser injector
- Diesel particulate filter (DPF)
- DPF air, fuel, coolant lines, manifold assembly
- DPF dosing module
- Exhaust gas recirculation (EGR) valves
- Exhaust gas temperature sensor
- EGR actuator, coolers, connecting bellows & clamps
- Exhaust piping, clamps, gaskets and throttle valve
- Hydrocarbon doser injector (HC doser, 7th injector, ARD, AHI module)
- Hydrocarbon doser valve - air, fuel, coolant lines; and inline air filter and Voss valve
- Selective catalytic reduction (SCR) catalyst
- SCR decomposition pipe and pipe elbows
- Sensor, BPV pressure
- Sensor, delta P (DPF pressure/DPF soot/particulate level sensor)
- Sensors, DOC inlet pressure & DOC (post/pre) temp
- Sensor, DPF air supply pressure
- Sensors, DPF back pressure & DPF fuel pressure
- Sensor, lambda (O2 sensor)
- Sensor, NOX (2)
- Sensor, pressure after exhaust throttle valve
- Sensors, SCR (post/pre) temp
- Wiring harness - emission systems (incl. Overlay)

Towing reimbursement (3 instances)

INCLUDED